

# Magnetischer Ölstandsanzeiger Typ G 1 ½"

## *Magnetic Oil Level Indicator Type G 1 ½"*

### Einbauanleitung

Der magnetische Ölstandsanzeiger wird in das Füllrohr eingeschraubt.

Bei der Installation darf der maximale Winkel von 7 ° nicht überschritten werden.

#### **Die Anzeige wird wie folgt eingestellt:**

Nach dem die Ringmutter gelöst wurde, kann die Sichtkuppel entfernt und die Anzeigeeinheit mit Magnet entnommen werden. Die Anzeige sollte nun über die Zentrierschraube so eingestellt werden, dass bei korrektem Füllstand des Transformators nur die weiße Anzeige in der Sichtkuppel angezeigt wird. Senkt sich der Ölspiegel im Transformator, so erscheint die rote Anzeige im Schauglas.

### *Assembling instructions*

*The oil level indicator is to be screwed into the filling pipe. During assembly the maximum inclination angle is 7 °.*

#### **The indicating device has to be adjusted as follows:**

*After first unscrewing the ring nut, take off the viewing dome, remove the sealing ring and lift out the indicator scale complete with upper magnet. Now the scale can be turned into the correct position by loosening the center screw. If the transformer is properly filled, only the white indicator should be visible in the indicating field.*

*If the oil level drops, the red warning field appears.*

